

# **SCAG POWER EQUIPMENT**

## **SERVICE INFORMATION SHEET 142**

### **Replaceable Trim-Side Wear Pad for Advantage Cutter Decks**

All new Velocity Plus, 36" and 72" Advantage cutter decks are equipped with the replaceable trim-side wear pad as standard equipment. This wear pad helps to protect landscaping and the cutter deck from damage.

If you have a customer that would like to install this wear pad on an older Scag mower equipped with an Advantage cutter deck, it can be installed with little modification. Use the part numbers listed below for the correct replaceable trim-side wear pad.

**36" Advantage Cutter Deck (Walk-Behind) - 483174**

**36" Advantage Cutter Deck (Z-Cat) - 483175**

**42" Advantage Cutter Deck (Z-Cat) - 483175**

**48" Advantage Cutter Deck (All Models) - 483175**

**52" Advantage Cutter Deck (All Models) - 483175**

**61" Advantage Cutter Deck (All Models) - 483175**

**72" Advantage Cutter Deck (All Models) - 483174**

When installing the replaceable trim-side wear pad use the wear pad as a guide to mark the mounting holes. Drill the holes into the trim-side of the cutter deck using an 11/32" drill. Secure using (2) two 5/16-18 x 3/4" bolts, (2) two 5/16" flatwashers and (2) two 5/16-18 center lock nuts. The hardware must be installed from the inside of the deck facing outward with the center lock nuts on the outside.

This is a product enhancement and is not warrantable.